ORDER NO. RD82065291C2

Service Manual

Radio Cassette

RX-C100LS

Portable Component System with 4-Band Radio

■ SPECIFICATIONS

General:

Power Requirement:	AC; 110~115/115~127/200~220/230~250V, 50/60Hz Battery; 15V (The "D" Size Flashlight Batteries) (National UM-1 or equivalent) Car battery; with optional car battery cord RP-9550
Power Consumption:	65W (AC only)
Power Output:	40W (20W×2)...RMS (max.) 40W (20W×2)...MPO
Speaker:	Woofer; 16cm ($6^1/_2$") PM Dynamic Speaker (8Ω) Tweeter; 6.5cm ($2^1/_2$") PM Dynamic Speaker (8Ω)
Input:	MIC; sensitivity 0.26mV/applicable microphone impedance 200~600Ω MIX MIC; sensitivity 0.8mV Phono; sensitivity 2.5mV/47kΩ DC IN; 13.2 (12~15V)
Output:	EXT Speaker; 8Ω Headphones; 0.5mW/8Ω
REC/PB Connection:	5P DIN type IN; 18mV/6kΩ OUT; 420mV/10kΩ
Dimensions:	Total Size 708(W)×256(H)×217(D)mm ($27^7/_8$"×$10^1/_8$"×$8^1/_2$") Main Unit 348(W)×256(H)×217(D)mm ($13^{11}/_{16}$"×$10^1/_8$"×$8^1/_2$") Speaker Box 185(W)×256(H)×180(D)mm ($7^1/_4$"×$10^1/_8$"×$7^1/_8$")
Weight:	11.14kg (24 lb. 11 oz.) without batteries

Radio Section:

Radio Frequency Range:	FM; 87.5~108MHz LW; 150~285kHz (2000~1060m) MW; 520~1610kHz (577~186m) SW; 5.9~18MHz (50.8~16.7m)
Intermediate Frequency:	FM; 10.7MHz AM (LW/MW & SW); 455kHz
Sensitivity:	FM; 2μV/50mW output LW; 100μV/m/50mW output MW; 57μV/m/50mW output SW; 16μV/50mV output

Tape Deck Section:

Frequency Response:	40~12,000Hz (with normal tape) 40~14,000Hz (with CrO_2 tape) 40~16,000Hz (with Metal tape)
Recording System:	AC bias, AC erase
Tape Speed:	4.8cm/s, ($1^7/_8$" ips)
Wow and Flutter:	0.055% (WRMS)
Program Time:	1 hour with C-60 cassette tape
Track System:	4-track 2-channel stereo recording and playback

Specifications are subject to change without notice.

Panasonic

Matsushita Electric Trading Co., Ltd.
P.O. Box 288, Central Osaka Japan

LOCATION OF CONTROLS AND COMPONENTS



Fig. 1



Fig. 2



Fig. 3



Fig. 4

① VU Meter (VU)
② Recording Indicator (REC)
③ Dolby Noise Reduction Indicator (DOLBY NR)
④ Tuning Indicator (TUNE)
⑤ FM Stereo Indicator (FM ST)
⑥ Power/Battery Check Indicator (power/batt)
⑦ Tape Program Sensing Indicator (TPS)
⑧ FL Meter Switch (on/off)
⑨ Tape Program Sensor Switch (on/off)
⑩ FM Muting Switch (on/off)
⑪ Dial Light Switch (on/off)
⑫ Balance Control (balance)
⑬ Volume Control (volume)
⑭ Loudness Switch (on/off)
⑮ Mode Selector (mono, stereo)
⑯ Dolby Noise Reduction Switch (in/out)
⑰ Tape Selector (normal/CrO_2/metal)
⑱ Recording Level Control (rec level)
⑲ Function Selector (power off, tape/radio/phono/DIN)
⑳ Band Selector (FM/LW/MW/SW)
㉑ Tuning Control (tuning)
㉒ Fine Tuning Control (fine tuning)
㉓ Speakers (tweeter) 6.5cm ($2^1/_2$") 8Ω
㉔ Speakers (woofer) 16cm ($6^1/_2$") 8Ω
㉕ Built-in Microphones (MIC)
㉖ Cassette Compartment
㉗ Tape Counter and Reset Button (counter/reset)
㉘ Graphic Equalizer Controls (graphic equalizer)
㉙ Eject Button (eject)
㉚ Record Button (record)
㉛ Rewind Button (rewind)
㉜ Fast Forward Button (ff)
㉝ Playback Button (play)
㉞ Stop Button (stop)
㉟ Pause Button (pause)
㊱ Record Muting Button (rec mute)
㊲ Mixing Level Control (mixing level)
㊳ Mixing Microphone Jack (mic), 0.8mV
㊴ Headphone Jack (phones), 0.5mW/8Ω
㊵ Speaker Wall Mounts
㊶ Speaker Terminals
㊷ External Antenna Terminals (FM ANT/AM ANT)
㊸ Phono Input Jacks (PHONO), 2.5mV/47kΩ over
㊹ Telescopic Antenna
㊺ Phono Ground Terminal (EARTH)
㊻ Din Connector Jack (DIN) IN...18mV/6kΩ, OUT...420mV/10kΩ
㊼ Microphone Jacks (MIC), 0.26mV/200~600Ω
㊽ Beat Proof Switch (BEAT PROOF I/II/III)
49 Speaker Lock Buttons
50 Speaker Cable Compartments
51 DC Input Jack [DC In 13.2V (12~15V) ⊖—◉— ⊕]
52 AC Socket (AC IN~)
53 Voltage Selector (VOLTAGE SELECTOR)
54 Battery Compartment

DOLBY SYSTEM

*"Dolby" and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.
*Noise reduction system manufactured under license from Dolby Laboratories Licensing Corporation.

DISASSEMBLY INSTRUCTIONS



Fig. 5



Fig. 6



Fig. 7



Fig. 8



Fig. 9



Fig. 10



Fig. 11



Fig. 12



Fig. 13



Fig. 14

SCHEMATIC DIAGRAM (AUDIO) MODEL RX-C100LS


Q106, 206 2SC1327 DIN AMP
IC102 RVIBA328 TAPE AMP
IC101 RVIBA328MR PHONO AMP
IC301 RVIBA1355 FM MPX
Q301 2SC1684 SWITCHING
Q401, 404 2SC1684 SWITCHING
Q402, 403, 405, 406 2SA564 SWITCHING
IC103, 203 RVINE649N DOLBY AMP
IC402, 403 RVIBA6146 FL DRIVE
Q101, 201 2SC2001 MUTING
D401, 402 MA150 DC-DC CONV
Q102, 202 2SC1684 REC AMP
Q407, 408 2SC1317 DC-DC CONV
Q103, 203 2SC1684 LINE AMP
IC401 RVIBA338 TPS CONTROL
Q409 2SC1317 LIGHT CONTROL
Q410 2SC1266 REGULATOR
D403, 404 LN02273P POWER/BATT TPS IND
Q411 2SD471 PLUNGER CONT
IC104, 204 RVIUPC1277H POWER AMP
Q104, 204 2SC1684 MUTING
D101, 201, 307 MA150 MUTING
Q501~506 2SC1684 EQ AMP
Q309 2SA564 MUTING
Q310, 311 2SC1684 SWITCHING
Q313 2SC2001 MUTING
DIN IN 18mV/6KΩ OUT 420mV/10KΩ
To Tuner
BIAS VOLTAGE METAL 8±0.3mV Normal 3.8±0.3mV
REC/PLAY HEAD
0.26mV J104 (200~600Ω) EXT MIC
BIAS OSCILLATOR 67±1kHz E-HEAD
D414 MA150 SWITCHING
FL METER
CH 1 LEVEL. STEREO · EYE . TUNING . REC . DOLBY · NR.
CH 2 LEVEL.
6.5cm (2½") TWEETER (8Ω)
16cm (6½") WOOFER (8Ω)
HEAD PHONES
AC IN J108
DC IN J107
BATT (15V)
Q314 2SC1684 MUTING
Q306, 307 2SC1317 BIAS OSC
Q302 304 2SC1684 MIXING AMP
D301 MA1056 REGULATOR
Q316 2SC1684 REC AMP
D302, 303 MA27WATA AOC
Q308 2SC1266 REGULATOR
D305 RVD10E1 PROTECTOR
D304 MA1110 REGULATOR
Q105, 205 2SC1684 MUTING
Q801 2SC1847 REGULATOR
D801 MA1180 REGULATOR
D413 RVDRD10EB2T REGULATOR
D701~704 RVDS4VB10F RECT
D411 MA1075 BATT CHECK
D409 MA150 BATT CHECK
D410 MA27WATA BATT CHECK
D705 RVDERD0302 PROTECTOR
D408 RVD10E1 PROTECTOR
Q601~606 2SC1684 EQ AMP

Notes

1. S
2. S
3. S
4. S
5. S
6. S
7. S
8. S
9. S
10. S
11. S
12. S
13. S
14. S
15. S
16. S
17. S
18. S
19. S
20. S
21. Th
22. Th
23. D
24. Ba
25. VR
26. VR
27. VR
28. VR
29. VR
30. VR
31. VR
32. VR
33. VR
34. VR
35. VR
36. VR
37. Im



Notes:

1. S2-1~S2-12 ...Record/playback switch in "playback" position (1...Playback, 3...Record).
2. S3-1~S3-6 ...Function switch in "power off/tape" position. (1...power off/tape, 2...radio, 3...phono, 4...DIN).
3. S4-1~S4-5 ...Tape select switch in "normal" position. (1...normal, 2...CrO_2, 3...metal).
4. S5-1, S5-2.....Mode switch in "stereo" position. (1...mono, 2...Stereo).
5. S6-1, S6-2.....Loudness switch in "on" position. (1...on, 2...off).
6. S7-1~S7-5 ...Dolby NR switch in "in" position. (1...in, 2...out).
7. S8 .....TPS switch in "on" position. (1...on, 2...off).
8. S9 .....FM Muting switch.
9. S10 .....FL meter switch in "on" position. (1...on, 2...off).
10. S11 .....Dial light switch in "off" position. (1...on, 2...off)
11. S12 .....Radio/phono/DIN switch in "off" position.
12. S13 .....FF/REW switch.
13. S14 .....Motor switch.
14. S15 .....Playback switch.
15. S16 .....TPS playback switch.
16. S17 .....Muting switch.
17. S18-1, S18-2...Rec mute switch.
18. S19 .....AC/DC IN select switch.
19. S20 .....Voltage select switch.
20. S21 .....Beat proof switch. (1...I, 2...II, 3...III).
21. The mark (▼) shows test point e.g. ▼1 = test point 1.
22. The marks (※) shows printed-type resistors.
23. DC voltage measurement are taken with electronics voltmeter from negative terminal of battery.
    [ ]...FM position, ( )...AM position,
    < >...Recording position.
24. Battery current: No signal.....250mA
    Maximum output (radio) 3.3A
    Maximum output (tape) 3.17A
25. VR101, 201 ...Bias Current adjustment VR. (Metal)
26. VR102, 202 ...Playback level adjustment VR.
27. VR103, 203 ...Overall gain adjustment VR.
28. VR104, 204 ...Volume control VR.
29. VR105, 205 ...Recording level control VR.
30. VR301 .....VCO adjustment VR.
31. VR302 .....Mixing control VR.
32. VR303 .....Bias current adjustment VR. (Normal)
33. VR304 .....Erase current adjustment VR.
34. VR305 .....Balance control VR.
35. VR401, 402 ...Meter adjustment VR.
36. VR501~505
    601~605 ...Graphic equalizer control VR.
37. Important safety notice
    Components identified by ⚠ mark have special characteristics important for safety.
    When replacing any of these components, use only manufacturer's specified parts.

▬▬	+ Ⓑ Voltage Line
▬▬	Record Signal Line
▬▬	Radio (FM) Signal Lin
▬▬	Playback Signal Line
▬▬	AF Signal Line

BIAS VOLTAGE 8±0.5mV (Metal)
5.2±0.5mV (CrO_2)
3.8±0.5mV (Normal)

OVERALL FREQUENCY RESPONSE

Metal	100Hz	1±3dB
	1kHz	0dB
	10kHz	0±5dB
CrO_2	100Hz	1±3dB
	1kHz	0dB
	10kHz	0±5dB
Normal	100Hz	1±3dB
	1kHz	0dB
	10kHz	0±5dB

■ SWITCH CIRCUIT BOARD







■ POWER SOURCE CIRCUIT BOARD



IC1 AN7220A



IC101, 102 RVIBA328MR, RVIBA328



IC103, 203 RVINE649N



IC401 RVIBA338



IC104, 204 RVIUPC1277H



FL DIAGRAM



Pin	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
	F	F	R1	R2	R3	R4	R5	R6	R7	R8	R9	R10	R11	R12	Gd	Sc	REC
18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35
FMST	TUNE	DOL • NR	L1	L2	L3	L4	L5	L6	L7	L8	L9	L10	L11	L12	Np	F	F

IC BLOCK DIAGRAM

IC402, 403 RVIBA6146



IC301 RVIBA1355





Fig. 15

■ CONNECTOR POSITION



Fig. 16

CP7 : Headphone connector.
CP8 : Mixing Microphone jack connector.
CP9 : Mechanism connector.
CP10: Mechanism connector.
CP11: Motor connector.
CP12: Record/playback head connector.
CP13: Erase head connector.
CP14: Rec mute switch connector.
CP16: Built-in microphone connector (L)
CP17: Built-in microphone connector (R)

DIAL THREADING

Cord length is 180cm ($71^{3}/_{16}$").



Fig. 17

Procedure	To remove —.	Remove	Shown in Fig. —.
1	Front Cabinet	Battery Compartment .....(A)×1	5
2		Screw (3×50) .....(B)×2	5
3		Screw (3×8) .....(C)×4	6, 7
4		Socket .....(D)×1	15
5	Chassis	Knob .....(E)×9	8
6		Spring .....(F)×1	9
7		Screw (RHD350Z) .....(G)×2	9
8		Screw (3×10) .....(H)×3	10
9	Dial Scale	Screw (3×6) .....(I)×3	11
10		Twist the log of dial scale .....(J)×2	11
11	Meter Circuit Board	Push the catch in the direction of arrows .....(K)×4	12
12		Lever .....(L)×4	12
13		Socket & Lamp .....(M)×7	13
14		Screw (3×6) .....(N)×6	13
15	Mechanism	Remove the cassette panel in the direction of arrow .....(O)×1	8
16		Screw (3×10) .....(P)×4	14
17	Equalizer Circuit Board	Knob .....(Q)×5	8
18		Screw (3×10) .....(R)×4	14
19		Unsolder lead wire .....(S)×1	14
20	Headphone Circuit Board	Knob .....(T)×1	8
21		Screw (3×10) .....(U)×2	14
22	Power Transformer	Screw (3×12) .....(V)×3	15
23	AC Jack Board	Screw (3×12) .....(W)×1	15
24		Screw (3×12) .....(X)×1	15
25		Cover .....(Y)×1	15
26		Screw (3×10) .....(Z)×2	15

BLOCK DIAGRAM

<RADIO>



<RECORDING> (L ch)



<PLAYBACK> (L ch)



Fig. 18

■ ALIGNMEN

			1. Set volu 2. Set grap 3. Set ban 4. Set bala 5. Set func

■ LW, MW an

	BAND	C	
(1)	MW		Fas sev wire sign rec
(2)	LW		
(3)	LW		
(4)	MW		
(5)	MW		
	(*1) Cemen		
(6)	SW		Cor poi cer (10 sid
(7)	SW		sid

■ FM ALIGN

	BAND	C	
(1)	FM		Cor poi 0.0 sid
(2)	FM		



MEASUREMENTS AND ALIGNMENTS

■ ALIGNMENT INSTRUCTION

READ CAREFULLY BEFORE ATTEMPTING ALIGNMENT

1. Set volume control to maximum.
2. Set graphic equalizer to center.
3. Set band switch to LW, MW, SW or FM.
4. Set balance control to center.
5. Set function selector to radio.
6. Set fine tuning to center.
7. Set power source voltage to 15V DC.
8. Output of signal generator should be no higher than necessary to obtain an output reading.

■ LW, MW and SW ALIGNMENT

	BAND	SIGNAL GENERATOR or SWEEP GENERATOR CONNECTIONS	SIGNAL GENERATOR or SWEEP GENERATOR FREQUENCY	RADIO DIAL SETTING	INDICATOR (ELECTRONICS VOLTMETER or SCOPE)	ADJUSTMENT	REMARKS
			AM-IF ALIGNMENT				
(1)	MW	Fashion loop of several turns of wire and radiate signal into loop of receiver.	455kHz 30% Mod. at 400Hz	Point of non-interference. (on/about 600kHz)	Output meter across voice coil.	T2 (AM IFT)	Adjust for maximum output.
			LW-RF ALIGNMENT				
(2)	LW	〃	145kHz	145kHz [20.04mm ($^{25}/_{32}$"])	Output meter across voice coil.	L8 (LW OSC Coil) (*1) L4 (LW ANT Coil)	Adjust for maximum output. Adjust L4 by moving coil bobbin along ferrite core.
(3)	LW	〃	285kHz	285kHz [167.89mm ($6^{19}/_{32}$")]	〃	CT5 (LW OSC Trimmer) CT1 (LW ANT Trimmer)	Adjust for maximum output. Repeat steps (2) and (3).
			MW-RF ALIGNMENT				
(4)	MW	〃	550kHz	550kHz [20.04mm ($^{25}/_{32}$")]	Output meter across voice coil.	L9 (MW OSC Coil) (*1) L3 (MW ANT Coil)	Adjust for maximum output. Adjust L3 by moving coil bobbin along ferrite core.
(5)	MW	〃	1,500kHz	1,500kHz [167.89mm ($6^{19}/_{32}$")]	〃	CT6 (MW OSC Trimmer) CT2 (MW ANT Trimmer)	Adjust for maximum output. Repeat steps (4) and (5).
	(*1) Cement antenna bobbin with wax after completing alignment.						
			SW-RF ALIGNMENT				
(6)	SW	Connect to test point ③ through ceramic capacitor (10pF). Negative side to test point ④.	5.9MHz	5.9MHz [7.0mm ($^{5}/_{16}$")]	Output meter across voice coil.	L10 (SW OSC Coil) L5 (SW ANT Coil)	Adjust for maximum output.
(7)	SW		18MHz	18MHz [177.24mm ($7^{13}/_{32}$")]	〃	CT7 (SW OSC Trimmer)	Adjust for maximum output. Repeat steps (6) and (7).

■ FM ALIGNMENT

	BAND	SIGNAL GENERATOR or SWEEP GENERATOR CONNECTIONS	SIGNAL GENERATOR or SWEEP GENERATOR FREQUENCY	RADIO DIAL SETTING	INDICATOR (ELECTRONICS VOLTMETER or SCOPE)	ADJUSTMENT	REMARKS
			FM-IF ALIGNMENT				
(1)	FM	Connect to test point ⑤ through 0.001μF. Negative side to test point ④.	10.7MHz (SWP.)	Point of non-interference. (on/about 90MHz)	Connect vert. amp. of scope to test point ⑥. Negative side to test point ⑦.	T1 (FM 1st IFT)	Adjust for maximum amplitude. (Refer to fig. 19.)
(2)	FM	〃	〃	〃	〃	T3 (FM 2nd IFT)	Adjust for maximum amplitude. (Refer to fig. 20.)
(3)	FM	Connect to test point ③ through FM dummy antenna. Negative side to test point ④.	90MHz	90MHz [30.0mm ($1^{3}/_{16}$")]	Output meter across voice coil.	L7 (FM OSC Coil) L1 (FM ANT Coil)	(*2) Adjust for maximum output.
(4)	FM		106MHz	106MHz [158.3mm ($6^{7}/_{32}$")]	〃	CT8 (FM OSC Trimmer) CT4 (FM ANT Trimmer)	(*2) Adjust for maximum output. Repeat steps (3) and (4).
	(*2) Three output responses will be present; proper tuning is the center frequency.						

■ SEPARATION ALIGNMENT

ITEM	FM SIGNAL GENERATOR SOURCE CONNECTION	EQUIPMENT CONNECTION ELECTRONIC COUNTER	ADJUSTMENT	SPECIFICATION	REMARKS
Adjustment of pilot signal.	98MHz, 60dB (Mod CW)	⑧ ...(+) ⑨ ...(−)	VR301	19kHz	Adjust VR301, for 19kHz (±150Hz) reading on electronics counter.

■ AUDIO ADJUSTMENT

ITEM	INPUT	MEASUREMENT POINT	SPECIFICATION	ADJUSTMENT POINT	REMARKS
Azimuth	QZZCFM (10kHz, −20dB)	SP	Maximum output.	Azimuth screw	Playback mode
Playback level	QZZCFM (315Hz, 0dB)	⑩ ...(Lch) ⑪ ...(Rch)	0.42±0.02V	VR102 (Lch) VR202 (Rch)	Playback mode Tape selector → Normal
FL meter (level)	QZZCFM (315Hz, 0dB)	VU Meter	"0" point	VR402 (Lch) VR401 (Rch)	Playback mode Tape selector → Normal
Bias oscillation frequency	——	㉚ ...(+) ㉜ ...(−)	66±0.5kHz	L302	Record mode Beat proof switch → I Tape selector → Metal
Erase current	Use metal tape	㉚ ...(+) ㉜ ...(−)	140±$^{3}_{5}$mV	VR304	Record mode Tape selector → Metal
Bias trap	——	② ...(Lch) ① ...(Rch) ㉝ ...(−)	0±1.5dB	L102 (Lch) L202 (Rch)	Record mode Beat proof switch...I → II Tape selector → Metal
Bias current	Use metal tape	② ...(Lch) ① ...(Rch) ㉝ ...(−)	Metal 8±0.3mV CrO_2 5.2±0.3mV Normal 3.8±0.3mV	Metal VR101 (Lch) VR201 (Rch) Normal VR303	Record mode Beat proof switch → II Tape selector → Metal
Overall gain	DIN f=1kHz, −52dB	DIN Jack Input ①, ④ pin Output ③, ⑤ pin	REC...250mV Playback... 250±10mV	VR103 (Lch) VR203 (Rch)	1. Place UNIT into record mode, and tape selector to normal. 2. Supply 1kHz (−52dB) from AF oscillator DIN IN. 3. Adjust REC LEVEL until monitor level at test point ⑩① and ⑳① becomes 250mV. 4. Playback recorded tape, and make sure the value at DIN OUT on the electronics voltmeter becomes 250mV±10mV



Fig. 19



Fig. 20

SCHEMATIC DIAGRAM (RADIO) MODEL RX-C100LS



<BOTTOM VIEW>



Notes:

1. S1-1∼S1-10: Band switch in "FM" position (1...FM, 2...LW, 3...MW, 4...SW).
2. DC voltage measurements are taken with electronics voltmeter from negative terminal of battery.
   ▭...FM position, ( )...MW position.
   ⟹ + Ⓑ Voltage Line
   ⟹ Radio (FM) Signal Line



■ METER CIRCUIT BOARD



■ LED CIRCUIT BOARD



CIRCUIT BOARD (RADIO, AUDIO) MODEL RX-C100LS





■ EQUALIZER CIRCUIT BOARD



■ ALIGNMENT POINT

* Please refer to Circuit Board which is located test point.



Fig. 21

WIRING CONNECTION DIAGRAM MODE



TION DIAGRAM MODEL RX-C100LS



■ PHONO CIRCUIT BOARD

IC101

1	1.4V	5	0V
2	0.9V	6	4V
3	3.8V	7	0.9V
4	9.4V	8	1.4V

Q106, 206

C	3.2V
B	0.7V
E	0.1V



■ REGULATOR CIRCUIT BOARD

Q801

C	14.9V
B	14.4V
E	13.7V



■ JACK CIRCUIT BOARD





MECHANISM PARTS LOCATION



Fig. 22

MECHANISM PARTS LOCATION



Fig. 23



Fig. 24

CABINET PARTS LOCATION



Fig. 25

SPEAKER BOX PARTS LOCATION



Fig. 26

ELECTRICAL PARTS LOCATION



Fig. 27



Fig. 28



Fig. 29



Fig. 30



Fig. 31



Fig. 32



Fig. 33

■ REPLACEMENT PARTS LIST .....Model RX-C100LS

(RD82065291C2)

NOTES: 1. Important safety notice.
Components identified by ⚠ mark have special characteristics important for safety.
When replacing any of these components, use only manufacturer's specified parts.
2. The S mark indicates service standard parts and may differ from production parts.

Ref. No.	Part No.	Part Name & Description	Per Set	Remarks
		MECHANICAL PARTS		
M1	QXA1044	Button Bracket Ass'y	1	
M2	QBP1875	Spring, Operation Rod	1	
M3	QMR1823	Lock Rod	1	
M4	QML3649	Lock Arm	1	
M5	QDG1102	Gear, Slow Up	1	
M6	QMN2554	Shaft, Operation Rod	1	
M7	QXL1513	Eject Lever Ass'y	1	
M8	QXL1514	Rec Lever Ass'y	1	
M9	QXL1515	Rewind Lever Ass'y	1	
M10	QXL1516	FF Lever Ass'y	1	
M11	QXL1517	Play Lever Ass'y	1	
M12	QXL1518	Stop Lever Ass'y	1	
M13	QXL1519	Pause Lever Ass'y	1	
			1	
M14	RYQXC1001N	Cassette Holder Ass'y	1	
M17	QBN1749	Spring, Cassette Slot	1	
M18	XUC5FT	Circlip	1	S
M19	XUC4FT	Circlip	2	S
M20	XTN26+6B	Screw	2	S
M21	QBT1597	Spring	1	
M22	XTN2+6B	Screw	1	S
M23	QWY4122Z	R/P Head	1	
M24	QWY2138Z	Erase Head	1	
M25	XSN2+9	Screw	4	
M26	QBP1873	Head Base Pressure Plate	1	
M27	XTN26+6B	Screw	7	S
M28	QMA3858	Head Plate	1	
M29	QDK1017	Steel Ball	3	
M30	XTN26+10B	Screw	2	S
M31	QMZ1240	Holder, Head Base	1	
M32	QBT1597	Spring	1	
M33	QML3591	Brake Arm	1	
M34	XTN26+12B	Screw	1	
M35	QBCA0008	Head Spring	1	
M36	QBC1278	Head Spring	1	
M37	QBN1740	Spring, R/P Head	1	
M38	QMZ1241	Head Spacer	1	
M39	QMK1840	Head Base Plate	1	
M40	QBT1892	Spring, Head Base Plate	1	
M41	QMN2550	Guide Roller	1	
M42	QBN1742	Spring, Pinch Roller	1	
M43	QXL1381	Pinch Roller Ass'y	1	
M44	QBN1743	Spring, Pinch Roller	1	
M45	RDH185Z	Cover	1	
M46	XTV26+6JFZ	Screw	5	
M47	RGX1130Z	Refrecting Plate	1	
M48	QBP1874	Cassette Holder Plate	1	
M49	QML3603	Safety Lever	1	
M50	QMR1822	Spring	1	
M51	QBN1747	Spring	1	
M52	QML3588	FF Spring Lever	1	
M53	QBN1748	FF Spring	1	
M54	QBW2008	Washer	6	
M55	QMB1336	Supply Drive Cam	1	
M56	QBC1306	Back Tension Spring	1	
M57	QDR1139	Supply Reel Table	1	
M58	QBW2012	Washer	2	
M59	QXD1143	Take Up Reel Table Ass'y	1	
M60	QXI0113	FF Idler Ass'y	1	
M61	QBT1893	Take Up Idler Spring	1	
M62	QXI0111	Take Up Idler Ass'y	1	
M63	QXL1382	Idler Lever Ass'y	1	
M64	QML3592	Change Lever	1	
M65	QBN1741	Lever Spring	1	
M66	QXL1383	FF Arm Ass'y	1	
M67	QXI0112	Rewind Idler Ass'y	1	
M68	QXL1354	Sub Lever Ass'y	1	
M69	QML3586	MS Lever	1	
M70	QBT1894	Main Lever Spring	1	
M71	QXL1355	Main Lever Ass'y	1	
M72	QDP1828	FF Pulley	1	
M73	QML3605	Auto Stop Detector Lever	1	
M74	QBN1746	Auto Stop Lever Spring	1	
M75	QML3594	Auto Stop Release Lever	1	
M76	QML3604	Auto Stop Driver Lever	1	
M77	QMR1821	Auto Stop Connection Rod	1	
M78	QXU0303	Motor Ass'y	1	
M79	QXA1042	Bracket Ass'y Plunger	1	
M80	XTN3+24B	Screw	1	
M81	QME0157	Plunger	1	
M82	QBC1358	Spring	1	
M83	XSN3+6S	Screw	2	S
M84	XWC3B	Washer	2	S
M85	XUC3FT	Circlip	1	S
M86	QML3616	Pause Driving Lever	1	
M87	QMZ1239	Flywheel Thrust Retainer	1	
M88	XUB3FT	Circlip	5	S
M89	QML3581	Sub Operation Lever	1	
M90	QBN1744	Sub Gear Spring	1	
M91	QDB0281	Capstan Belt	1	
M92	QBW2049	Washer	1	
M93	QXF0164	Flywheel Ass'y	1	
M94	QDG1202	Sub Gear	1	
M95	QML3582	Pause Lock Lever	1	
M96	QBT1896	Lever Spring	1	
M97	QBS1128	Lock Pin	1	
M98	QBC1357	Lock Pin Spring	1	
M99	XUB4FT	Circlip	1	S
M100	QDG1201	Main Gear	1	
M101	QXP0607	FF Belt Pulley Ass'y	1	
M102	QDB0274	Rewind Belt	1	
M103	QBW2012	Washer	1	

Ref. No.	Part No.	Part Name & Description	Per Set	Remarks
M104	QBN1745	Main Gear Spring	1	
M105	QMR1824	Control Rod	1	
M106	QML3583	Main Operation Lever	1	
M107	QML3584	Reverse Lever	1	
M108	QMR1820	Record Rod	1	
M109	QXL1360	R/P Selector Arm Ass'y	1	
M110	QML3580	R/P Selector Lever	1	
M111	QBN1739	Selector Lever Spring	1	
M112	QBT1895	R/P Pressure Spring	1	
M113	QXK2276	Lower Base Plate	1	
M114	QDP1823	Connection Pulley	1	
M115	QXG1047	Take Up Gear Ass'y	1	
M116	QDG1200	Cam Gear	1	
M117	QDG1199	Auto Stop Gear	1	
M118	QHQ1303	Screw	2	
M119	QBG1373	Cushion	1	
M120	QBG1683	Cushion	1	
M121	QXK2286	Sub Chassis Ass'y	1	
M122	QDB0273	Fast Forward Belt	1	
M123	XTN3+10B	Screw	2	S
M124	QMK1838	Upper Deck	1	
M125	XTN2+20F	Screw	1	
M126	QMF2118	Fitting Plate	1	
M127	QBT1682	Lock Spring	1	
M128	QBW2020	Washer	1	
M129	RSE90Z	Counter	1	
M130	QDB0207	Belt	1	
M131	RUB264Z	Lever	1	
M132	RHD100Z	Screw, Lever M'tg	1	
M133	RKE406Z	Cover, Mechanism (Metallic Silver)	1	
M133	RKE406Z1	Cover, Mechanism (Metallic Brown)	1	
M134	XTV3+10G	Screw, Cover M'tg	1	
M135	XSN3+6S	Screw, Bracket M'tg	4	S
M136	XWG3	Washer	4	S
M137	XWA2B	Washer	1	S
		INTEGRATED CIRCUITS, TRANSISTORS AND DIODES		
IC1	AN7220A	IC	1	
IC101	RVIBA328MR	IC	1	
IC102	RVIBA328	IC	1	
IC103,203	RVINE649N	IC	2	
IC104,204	RVIUPC1277H	IC	2	
IC301	RVIBA1355	IC	1	
IC401	RVIBA338	IC	1	
IC402,403	RVIBA6146	IC	2	
Q1	2SK195H1	Transistor (Si)	1	
Q2,4	2SC1359B	Transistor (Si)	2	S
Q3	2SC1674L	Transistor (Si)	1	
Q5∿7,102, 105,202, 301,304, 314,316,	104, 204,205, 310,311, 401,404			
	2SC1685-Q	Transistor (Si)	17	S
Q8,501∿506,601∿606				
	2SC1684S	Transistor (Si)	13	

Ref. No.	Part No.	Part Name & Description	Per Set	Remarks
Q101,201,	313			
	2SC2001K2	Transistor (Si)	3	
Q103,203	2SC1684HR	Transistor (Si)	2	
Q106,206	2SC1327T	Transistor (Si)	2	
Q302,303	2SC1684HS	Transistor (Si)	2	
Q306,307,	407∿409			
	2SC1317NCR	Transistor (Si)	5	
Q308,410	2SD1266R	Transistor (Si)	2	
Q309,402,	403,405,406			
	2SA722-S	Transistor (Ge)	5	S
Q411	2SD471L	Transistor (Si)	1	
Q801	2SC1847Q	Transistor (Si)	1	S
D1	RVDSD113	Diode (Si)	1	S
D2∿7,101, 401,402,	201,307, 409,414			
	MA161	Diode (Si)	13	S
D301	MA1056	Diode (Si)	1	S
D302,303,	410			
	MA27WA	Diode (Si)	3	
D304	MA1110L	Diode (Si)	1	
D305,408	SM112	Diode (Si)	2	S
D403,404	LN02273P	LED (Ga)	1	
D411	RVDRD7R5FB	Diode (Si)	1	S
D413	RVDRD10EB2	Diode (Si)	1	
D701∿704	RVDS4VB10F	Diode (Si)	1	
D705	RVDERD0302LF	Diode (Si)	1	
D801	MA1180	Diode (Si)	1	
		THERMISTOR		
TH1	RRT202	Thermistor	1	
		COILS AND TRANSFORMERS		
L1	RLO4Y26	Coil, FM Antenna	1	
L3,4	RLF6D16	Coil, LW,MW Antenna	1	
L5	QLA3M8	Coil, SW Antenna	1	
L7	RLO4Y27	Coil, FM Oscillator	1	
L8	RLO1M4	Coil, LW Oscillator	1	
L9	RLO2M14	Coil, MW Oscillator	1	
L10	RLO3M31	Coil, SW Oscillator	1	
L101,201	RLE5029	Coil, Dolby	2	
L102,202	QLQM1531	Coil, Bias Trap	2	
L103,203	RLQZ8221	Coil, Choke	2	
L301	QLM1M2	Coil, MPX	1	
L302	RLO9C23	Coil, Bias Oscillator	1	
L305	RLQZZ470	Coil,Filter	1	
T1,3	RLI4M101	IFT, FM	2	S
T2	QLI2M102M	IFT,LW	1	
T401	RLT9F3A	DC/DC Converter	1	
T701	RLT5M5Z1C	Power Transformer	1	⚠
		VARIABLE RESISTORS		
VR101,201	EVNM4AA00B15	Variable Resistor, Preset, 100kΩ (B)	2	S
VR102,202	EVNM4AA00B24	Variable Resistor, Preset, 20kΩ (B)	2	S

Ref. No.	Part No.	Part Name & Description	Per Set	Remarks
VR103,203,401,402				
	EVNM4AA00B54	Variable Resistor, Preset, 50kΩ (B)	4	S
VR104,204	EWCTNAF15B54	Variable Resistor, 50kΩ (B)	1	
VR105,205	RVV2B3B24	Variable Resistor, 20kΩ (B)	1	
VR301	EVNM4AA00B14	Variable Resistor, Preset, 10kΩ (B)	1	S
VR302	EWHFWAF15A14	Variable Resistor, 10kΩ (A)	1	
VR303,304	EVNM4AA00B53	Variable Resistor, Preset, 5kΩ (B)	2	S
VR305	EWHFXAF15G54	Variable Resistor, 50kΩ (G)	1	
VR501∿505,601∿605				
	EVBU02D20G54	Variable Resistor, 50kΩ (G)	5	
		VARIABLE CAPACITORS		
VC1∿4	RCV4RC7VK	Tuning Capacitor, w/Trimmer Capacitor (CT2,4,6,8)	1	
VC5	RCVMH8NC15	Fine Tuning	1	
CT7	RCVTZ11F	Trimmer Capacitor	1	
CT1,5	RCVTZ20F	Trimmer Capacitor	2	
		CERAMIC FILTERS		
CF1,2	RVF107MTWAR	Ceramic Filter	2	
CF3	RVFSFZ455A	Ceramic Filter	1	
		COMPONENT COMBINATION		
Z1	RXABPMF4W	Component Combination	1	
		SPEAKERS		
	EAS16PL216S	Speaker, 16cm (6-1/2"), 8Ω, Woofer	2	
	EAS65PH64S	Speaker, 6.5cm (2-1/2"), 8Ω, Tweeter	2	
		SWITCHES		
S1	RSR4J05Z	Switch, Band	1	
S2	RSH2L07Z	Switch, Record/Playback	1	
S3,12	RSR4F04Z	Switch, Function	1	
S4	RSR3F07Z	Switch, Tape	1	
S5∿7	RSHX044Z	Switch, Mode, Loudness, Dolby NR	1	
S8∿11	RSHX043Y	Switch, TPS, FM Muting, FL Meter etc.	1	
S13	QSB0253	Switch, TPS	1	
S14,15	QSB0254	Switch, Motor, Play	1	
S16	QSB0275	Switch, TPS , FF/REW	1	
S17	RSH2A10Z	Switch, Muting	1	
S18	RSH2A02Z	Switch, Rec Mute	1	
S20	RSR4A07Z	Switch, Voltage Selector	1	⚠
S21	RSS3A06Z	Switch, Beat Proof	1	
		JACKS		
J101,201	RJF1087Z	Jack, Phone	1	
J104,204	RJJ1D7Z	Jack, Microphone	2	
J105,205	RJF1088Z	Jack, Speaker Socket	2	
J106	RJJ1E2Z	Jack, Headphone	1	

Ref. No.	Part No.	Part Name & Description	Per Set	Remarks
J107,108	RJJ1F2Z	Jack, AC/DC IN	1	⚠
J109	RJJ1E7Z	Jack, Mixing	1	
J110	RJS15A	Jack, DIN	1	
		RESISTORS (Value is in OHMS)		
R308,420	ERD25FJ2R2	2.2 1/4W Carbon	2	S
R17	ERD25FJ470	47 " "	1	S
R149,153,249,253,301				
	ERD25FJ1R0	1 " "	5	S
R101,201	ERD25FJ100	10 " "	2	S
R367	ERD25FJ150	15 " "	1	S
R175,275	ERD25FJ820	82 " "	2	S
R150,151,171,250, 251,271,503,603				
	ERD25FJ101	100 " "	8	S
R2,28,143,165, 179,265,279, 352,360,435				
	ERD25FJ102	1 k " "	10	S
R4,107,115,129, 136,152,177,207, 215,229,236,252, 277,411,345,436				
	ERD25FJ103	10 k " "	16	S
R1,3,108,167, .208,267,329,401, 403,404,406,409, 413,437,438,513, 519,613,619				
	ERD25TJ104	100 k " "	19	S
R127,174,227,274				
	ERD25TJ105	1 M " "	4	S
R139,239	ERD25FJ151	150 " "	2	S
R312	ERD25TJ155	1.5 M " "	1	S
R119,219	ERD25FJ183	18 k " "	2	S
R126,134,226,234				
	ERD25TJ184	180 k " "	4	S
R5,8	ERD25FJ220	22 " "	2	S
R9,170,270				
	ERD25FJ222	2.2 k " "	3	S
R12,24,407, 408,425,426				
	ERD25TJ224	220 k " "	6	S
R111,211	ERD25FJ270	27 " "	2	S
R133,233,333				
	ERD25FJ272	2.7 k " "	3	S
R121,221,310				
	ERD25FJ273	27 k " "	3	S
R125,225	ERD25TJ274	270 k " "	2	S
R147,247,334,432, 511,514,517,520, 611,614,617,620				
	ERD25FJ331	330 " "	12	S
R135	ERD25FJ333	33 k " "	1	S
R114,214,505,605				
	ERD25FJ392	3.9 k " "	4	S

Ref. No.	Part No.	Part Name & Description	Per Set	Remarks
R124,141,142,224, 241,242,327,344, 441,502,506,602, 606,178,278	ERD25FJ332	3.3 k 1/4W Carbon	15	S
R26,109,209,523,623	ERD25FJ471	470 " "	5	S
R112,117,137,140, 146,148,173,212, 213,217,237,240, 246,248,273,416, 417,430,522,622	ERD25FJ472	4.7 k " "	20	S
R123,223	ERD25FJ473	47 k " "	2	S
R15,43,326	ERD25TJ474	470 k " "	3	S
R339,340,427	ERD25FJ562	5.6 k " "	3	S
R130,230,351	ERD25FJ563	56 k " "	3	S
R176,276,509,512, 515,518,521,609, 612,615,618,621	ERD25FJ682	6.8 k " "	12	S
R145,245,405,410, 412,414,504,604	ERD25TJ684	680 k " "	8	S
R16,138,238,335,431	ERD25FJ821	820 " "	5	S
R110,220,516,616	ERD25TJ823	82 k " "	4	S
R418,419	ERD25FJ122	1.2 k " "	2	S
R429,434	ERD25FJ152	1.5 k " "	2	S
R422	ERD25FJ153	15 k " "	1	S
R311,332,349,350, 428,433,580	ERD25FJ221	220 " "	7	S
R423,424	ERD25FJ223	22 k " "	2	S
R421	ERD25FJ561	560 " "	1	S
R507,510,607,610	ERD25TJ124	120 k " "	4	S
R550,650	ERD25FJ271	270 " "	2	S
R508,608	ERD25FJ391	390 " "	2	S
R501,601	ERD25FJ822	8.2 k " "	2	S
R801	ERD25FJ821	820 " "	1	S
R440	ERD25TJ334	330 k " "	1	S
R35	ERD25FJ123	12 k " "	1	S
R363	ERD25FJ3R3	3.3 " "	1	S
R365	ERD25FJ330	33 P " "	1	S
R348	ERG1ANJ680	68 P 1W Metal Oxide	1	S
R323	ERG1ANJ101	100 P " "	1	S
		CAPACITORS (Value is in MICRO FARADS except P.P=PICO FARADS)		
C60	ECCD1H1R5C	1.5 50V Ceramic	1	
C3,4,6,14	ECCD1H100KC	10 P " "	4	

Ref. No.	Part No.	Part Name & Description	Per Set	Remarks
C21	ECCD1H120KC	12 P 50V Ceramic	1	
C5	ECCD1H150KC	15 P " "	1	
C43,58	ECCD1H470KC	47 P " "	2	
C165,265,514,614	ECCD1H101K	100 P " "	4	
C429	ECKD1H332MD	0.0033 " "	1	
C25,347	ECKD1H103ZF	0.01 " "	2	
C701~706	ECKD1H333ZF	0.033 " "	6	
C316	ECKD1H222MD	0.0022 " "	1	
C315,508,608	ECKD1H472MD	0.0047 " "	3	
C64,314,349,166,266	ECKD1H102MD	0.001 " "	5	
C163,263	ECKD1H102ZF	0.001 " "	2	
C105,205,124, 224,512,612	ECKD1H471KB	470 P " "	6	
C510,610	ECKD1H152MD	0.0015 " "	2	
C127,227	ECQS2B331JZ	330 P 125V Styrol	2	
C307	ECQS2B471JZ	470 P " "	1	
C302	ECQV05223JZ	0.022 50V Polyester	1	
C135,141,148, 235,241,248	ECQV05224JZ	0.22 " "	6	
C355	ECQV05683JZ	0.068 " "	1	
C27	RCQP2A361JZ	360 P 100V "	1	
C66	ECQP1151JZ	150 P 125V "	1	
C26	ECQP1221JZ	1200 P 125V "	1	
C28	RCQP2A392JZ	3900 P 100V "	1	
C131,231,506, 513,606,613	ECFT1E153MD	0.015 25V Semi-Conductor	6	
C8,42,56,67,409,415	ECFT1E223MD	0.022 " "	6	
C118,218	ECFT1E273KD	0.027 " "	2	
C30,34,55,108, 110,208,210	ECFT1E333MD	0.033 " "	7	
C117,217	ECFT1E472KA	0.0047 " "	2	
C29,122,134,222, 234,304,407,408, 426,428,504, 511,604,611	ECFT1E473MD	0.047 " "	14	
C123,223	ECFT1E562KA	0.0056 " "	2	
C39,40,416,421	ECFT1E683MD	0.068 " "	4	
C107,207	ECFT1E103MD	0.01 " "	2	
C35,47,109,142,147, 209,242,247,336, 339,348,356,417	ECEA1AS101	100 10V Electrolytic	13	S
C329,345	ECEA0JS102	1000 6.3V "	2	S
C352	ECEA0JS222	2200 " "	1	S
C305,338,580	ECEA1AS221	220 10V "	3	S

Ref. No.	Part No.	Part Name & Description			Per Set	Remarks
C106,144,146,206, 244,246,340,353	ECEA1AS470	47	10V	Electrolytic	8	S
C327	ECEA1CS330	33	16V	"	1	S
C116,402,420	ECEA1AS471	470	10V	"	3	S
C48,102,103,114, 121,130,153,202, 203,214,221,230, 253,331,337,401, 404,413,419,431, 503,550,603,650, 801	ECEA1HS100	10	50V	"	25	S
C312,322,323,802	ECEA1ES101	100	25V	"	4	S
C342	ECEA1CS102	1000	16V	"	1	S
C325	ECEA1ES221	220	25V	"	1	S
C111,112,126,129, 137,162,164,211, 212,226,229,237, 262,264,328	ECEA50Z3R3	3.3	50V	"	15	S
C36,49,50, 154,254,414	ECEA25Z4R7	4.7	25V	"	6	S
C143,243	ECEA1ES470	47	"	"	2	S
C160,260,308,405, 406,509,609	ECEA1HSR22	0.22	50V	"	7	
C115,119,215, 219,319,410	ECEA1HSR33	0.33	"	"	6	
C309,411,507,607	ECEA50ZR47	0.47	"	"	4	S
C41,120,138,161, 220,238,261,311	ECEA1HS0R1	0.1	"	"	8	
C46,125,136,140, 225,236,240,310, 335,341,350,351, 412,501,502,505, 601,602,605	ECEA50Z1	1	"	"	19	S
C403	ECEA1AS102	1000	10V	"	1	S
C418	ECEA1CS221	220	16V	"	1	S
C332	ECES1EV472	4700	25V	"	1	
C1,2,9,32,33, 157,159,257,259, 321,343,422,423	ECBS1C103NY	0.01	16V	Ceramic	13	
C139,239	ECBS1E152MX	0.0015	25V	"	2	
C156,256	ECBS1E332MX	0.0033	"	"	2	
C18	ECBS1H1ROML	1.0	50V	"	1	
C13	ECBS1H100JC	10 P	"	"	1	
C44,101,201	ECBS1H101JL	100 P	"	"	3	

Ref. No.	Part No.	Part Name & Description			Per Set	Remarks
C10,11,24,54,61 145,155,156, 245,255,256	ECBS1H102KB	0.001	50V	Ceramic	11	
C15,23	ECBS1H150JC	15 P	"	"	2	
C7,12,16	ECBS1H180JC	18 P	"	"	3	
C17	ECBS1H3R3KC	3.3 P	"	"	1	
C37,52,53,62	ECBS1H331KB	330 P	"	"	4	
C22,330	ECBS1H391KB	390 P	"	"	2	
C19	ECBS1H4R7KC	4.7 P	"	"	1	
C45	ECBS1H560JL	56 P	"	"	1	
C104,204	ECBS1H681KB	680 P	"	"	2	
C65,313	ECBT1E103MM	0.01	25V	"	2	
C320,424,425,427	ECBT1E103NM	0.01	"	"	4	
C113,213	ECBT1E153MM	0.015	"	"	2	
C38	ECBT1C223MY	0.022	"	"	1	
C128,132,228,232,317	ECBT1H222MM	0.0022	50V	"	5	
C152,252	ECEA50N3R3	3.3	"	Electrolytic	2	
		CABINET PARTS				
K1	RYMXC100LSX8	Front Cabinet Ass'y (Metallic Silver)			1	
K1	RYMXC100LS91	Front Cabinet Ass'y (Metallic Brown)			1	
K1-1	RBC395Z	Button, Rec Mute			1	
K2	RYFXC100LSX8	Rear Cabinet Ass'y (Metallic Silver)			1	
K2	RYFXC100LS91	Rear Cabinet Ass'y (Metallic Brown)			1	
K2-1	RJT765Z	Terminal, Telescopic Antenna			1	
K2-2	RJC936Z	Terminal, Battery +, - Side			1	
K3	RYPXC100LSX2	Cassette Panel Ass'y (Metallic Silver)			1	
K3	RYPXC100LSXG	Cassette Panel Ass'y (Metallic Brown)			1	
K4	RYNX7000N7	Battery Cover Ass'y (Metallic Silver)			1	
K4	RYNXC100FX91	Battery Cover Ass'y (Metallic Brown)			1	
K5	RKX241Z	Handle (Metallic Silver)			1	
K5	RKX241Z2	Handle (Metallic Brown)			1	
K6	RBC393Z	Button, TPS, Meter etc.			4	
K7	RDS5093Z	Spring, Button			4	
K8	RBD170Z	Knob, Equalizer			5	
K9	RBN554Z	Knob, Fine Tuning, Balance			2	
K10	RBN561Y	Knob, Tuning			1	
K11	RBN586Y	Knob, Rec Level (Left)			1	
K12	RBN608Z	Knob, Rec Level (Right)			1	
K13	RBN607Z	Knob, Volume			1	
K14	RBS193X	Knob, Tape Selector, Band etc.			3	
K15	RBS193W	Knob, Mixing			1	
K16	RBC396Z	Button, Speaker Box Lock (Metallic Silver)			2	

Ref. No.	Part No.	Part Name & Description	Per Set	Remarks
K16	RBC396Z2	Button, Speaker Box Lock (Metallic Brown)	2	
K17	RUL662Z	Bracket, Button	2	
K18	RDS5133Z	Spring, Button	2	
K19	RKX180Y	Arm, Handle	2	
K20	RKT134Z	Stopper, Arm (Metallic Silver)	2	
K20	RKT134Z2	Stopper, Arm (Metallic Brown)	2	
K21	XEAQCR228FAK	Telescopic Antenna	1	
K22	RKE415Z	Cover, SP Cord Compartment (Metallic Silver)	2	
K22	RKE415Z2	Cover, SP Cord Compartment (Metallic Brown)	2	
K23	RKX207Z	Bracket, Handle	2	
K24	XYN3+F15FY	Screw, Telescopic Antenna M'tg (Metallic Silver)	1	
K24	XYN3+F15FZ	Screw, Telescopic Antenna M'tg (Metallic Brown)	1	
K25	XTC3+8CFN	Screw, Cabinet M'tg (Metallic Silver)	4	
K25	XTS3+8BFZ	Screw, Cabinet M'tg (Metallic Brown)	4	S
K26	XTV3+50G	Screw, Cabinet M'tg	2	
K27	XTB3+8CFN	Screw, Handle M'tg (Metallic Silver)	2	
K27	XTB3+8BFZ	Screw, Handle M'tg (Metallic Brown)	2	S
K28	XTS3+12CFN	Screw, Stopper M'tg (Metallic Silver)	2	
K28	XTS3+12CFZ	Screw, Stopper M'tg (Metallic Brown)	2	
K29	XTV3+10G	Screw, Bracket M'tg	2	
		SPEAKER BOX		
K30	RYMC1002N8	Speaker Box Ass'y, Left (Metallic Silver)	1	
K30	RYMC1002FX91	Speaker Box Ass'y, Left (Metallic Brown)	1	
K31	RYMC1003N8	Speaker Box Ass'y, Right (Metallic Silver)	1	
K31	RYMC1003FX91	Speaker Box Ass'y, Right (Metallic Brown)	1	
K32	RMS40Z	Bracket, Tweeter	4	
K33	RHG1049Z	Rubber, Tweeter	2	
K34	RKE413Z	Shaft, SP Box	2	
K35	RGM232Z	Metal Grille, Tweeter (Metallic Silver)	2	
K35	RGM232Z1	Metal Grille, Tweeter (Metallic Brown)	2	
K36	RGX1275Z	Ornament, Tweeter	2	
K37	RJF1089Z	Terminal, Speaker	2	
K38	RUL661Z	Bracket, SP Box (Metallic Silver)	1	
K38	RUL661Y	Bracket, SP Box (Metallic Brown)	1	
K39	RKF592Y7	Cover, SP Box (Metallic Silver)	2	
K39	RKF592Y1	Cover, SP Box (Metallic Brown)	2	

Ref. No.	Part No.	Part Name & Description	Per Set	Remarks
K40	XMM31+13FN	Screw, Cover M'tg (Metallic Silver)	20	
K40	XMM31+13FZ	Screw, Cover M'tg (Metallic Brown)	20	
K41	XTV3+12GFN	Screw, Bracket M'tg (Metallic Silver)	8	
K41	XTV3+12GFZ	Screw, Bracket M'tg (Metallic Brown)	8	
K42	XYN3+F16	Screw, Shaft M'tg	4	
K43	XTV3+10G	Screw, Speaker M'tg (Tweeter)	4	
K44	XTWR3+12Q	Screw, Speaker M'tg (Woofer)	8	
		ELECTRICAL PARTS		
E1	XBA2C50TR0	Fuse	2	⚠
E2	RUB263Z	Lever, Record/Playback	1	
E3	RDS3121Z	Spring, Lever	1	
E4	RADBG103ZS	Display Tube	1	
E5	RUS462Z	Spring, Display Tube	1	
E6	RDD4015Y	Drum, Dial	1	
E7	RDR20-3	Pulley, Dial	4	
E8	RDR21-1	Pulley	1	
E9	RDS3060A	Spring, Dial	1	
E10	RDZ05Z	Cord, Dial	1 ROLL	
E11	RDT9122Y	Shaft, Tuning	1	
E12	RUL681Z	Bracket, Display Tube	1	
E13	RNW150-2	Washer, Pulley	5	
E14	RKD613S	Scale, Dial (Metallic Silver)	1	
E14	RKD613W	Scale, Dial (Metallic Brown)	1	
E15	RDP845Z	Pointer, Dial	1	
E16	XAMR43T150A	Pilot Lamp, Dial	2	S
E17	RGL52Z	Panel, Pilot Lamp	1	
E18	RGP773Z	Panel, Display Tube	1	
E19	RBC394Z	Button, Loudness, Dolby NR etc.	3	
E20	RBZ515Z	Lever, Switch	4	
E21	RJF1046Z	Terminal, EXT Antenna	4	
E22	RJT764Z	Terminal, Telescopic Antenna	1	
E23	RJT514Z	Terminal, Earth	1	
E24	QTF1054	Terminal, Fuse	2	⚠
E25	RJC511Z	Terminal, Battery - Side	1	
E27	RUL683Z	Bracket, Circuit Board	1	
E28	RJS2L1Z	Socket, 2 Pin	5	
E29	RJS3L1Z	Socket, 3 Pin	7	
E30	RJS4L1Z	Socket, 4 Pin	1	
E31	RJS5L1Z	Socket, 5 Pin	4	
E32	RJS6L1Z	Socket, 6 Pin	1	
E33	RJP2G1Z	Plug, CP11, 16, 17	3	
E34	RJP2G2Z	Plug, CP1, 15	2	
E35	RJP3G1Z	Plug, CP13, 14, 18	3	
E36	RJP3G2Z	Plug, CP9, 6	2	
E37	RJP3G3Z	Plug, CP2, 3	2	
E38	RJP4G1Z	Plug, CP8	1	
E39	RJP5G1Z	Plug, CP7, 10	2	
E40	RJP5G2Z	Plug, CP4, 5	2	
E41	RJP6G1Z	Plug, CP12	1	
E42	RJT462Z	Terminal, Socket	60	
E43	RJM142Z	Microphone	2	

Ref. No.	Part No.	Part Name & Description	Per Set	Remarks
E44	RHD350Z	Screw, Record/Playback Lever M'tg	2	
E45	RHG416Z	Cover, Microphone	2	
E46	RJR1176Z	Spacer, Band Switch Shaft	1	
E47	RJT667Z	Terminal, Circuit Board	2	
E48	RMD1111Y	Bracket, Circuit Board	1	
E49	XANR2T20	Neon Lamp, Arrester	1	
E50	XSN26+5	Screw, Drum M'tg	1	S
E51	XWA26B	Washer	1	S
E52	XSN3+6S	Screw, Switch & Circuit Board M'tg	21	S
E53	XWA3B	Washer	7	S
E54	XSN3+8S	Screw, Panel M'tg	3	S
E55	XWG3	Washer	20	S
E56	XSN4+6S	Screw, Transformer M'tg	4	S
E57	XTV3+10G	Screw, Chassis M'tg	6	
E58	XTV3+10GR	Red Screw, Circuit Board M'tg	14	
E59	XTV3+12G	Screw, Transformer M'tg	4	
E60	XTW3+12F	Screw, Circuit Board M'tg	1	
E61	XTV3+8BFN	Screw, Transistor M'tg	5	S
E62	XTW3+8F	Screw, Transistor M'tg	1	
E63	XTV3+6F	Screw, Bracket M'tg	1	
E64	XNS11	Nut, Rec Level M'tg	1	S
E65	XNS8D	Nut, Balance, Volume etc. M'tg	3	
E66	RUV662Z	Holder, Read Wire	1	
E67	RUV676Z	Cover, Power Circuit Board	1	
		ACCESSORIES		
	RJA20Z	Power Cord, AC	1	⚠
	RJE123Z	Speaker Cord	2	
	RQE13Z	Caution Tag	1	
	RJN34Z	Cassette Tape	1	
		PACKING MATERIALS		
	XZB45X40A04	Polyethylene Cover	2	S
	XZB60X60A04	Polyethylene Cover	1	S
	RPN3672Z	Pad, Cassette Panel	1	
	RPN9411Z	Pad Complete	1	
	RPK1410Z	Gift Box	1	
		PRINTED MATERIAL		
	RQX6944Z	Instruction Book	1	

RD Ⓗ XG
Printed in Japan